



TRANSITION FOR B612 TO B618 CURB & GUTTER
AT CURB RETURNS

TRANSITION CURB: B612 TO B618 HL-356B

NOT TO SCALE